

# Bell Covers & Musicians' Masks

available from



Help keep yourself and others safe by wearing a mask and using a bell cover on your instrument. Preliminary results from the Performing Arts Aerosol Study have shown that wearing a mask and using a cover over the bell of your instrument, along with social distancing and other safety recommendations, can greatly reduce the transmission of air-borne particles produced while playing a wind instrument.



## Face Mask

BHMB Musician's Mask \$6.99

*Face mask has a hole in the middle of it through which to place the instrument mouthpiece so the mask can be worn while playing an instrument. One size fits all. Color: black. Made of a 2-ply polyester/spandex blend from 105 denier fabric.*

## Bell Covers:

BCXS-3": Oboe, Clarinet, Bassoon \$7.99

BCS-6": Alto & Tenor Saxophone, Trumpet/Cornet \$7.99

BCM-9" Tenor & Bass Trombone, Baritone Saxophone \$7.99

BCL-12": French Horn, Euphonium \$10.99

BCXL-17": Tuba \$10.99

BCXXL-24": Sousaphone \$10.99

*Color: black. Made of a polyester/spandex blend from 105 denier fabric.*

**Order online at [EllisMusic.com](http://EllisMusic.com) or by calling 802-234-6400**

*Prices valid as of 8/28/2020*