


## Information for Trumpet Players

- Store mouthpiece in designated slot in case
- Open water key and blow through instrument to remove water – especially after playing
- Move all 4 slides back and forth periodically to prevent sticking
- Oil valves as needed (only 2-3 drops)
- If mouthpiece gets stuck bring to your music teacher –NEVER remove any stuck object with pliers
- Tiny dents in the casings can cause your valves not to move
- Wash your mouthpiece with a mouthpiece brush in lukewarm water and soap as needed
- Make sure you set your trumpet down with the 2<sup>nd</sup> valve slide pointing up to help prevent the 2<sup>nd</sup> valve from sticking
- Do NOT eat or drink before or while you play
- Send in once a year for maintenance



*Accent On Achievement  
"trumpet" clip art  
Alfred Publishing Co.,  
Van Nuys, CA  
2009, 2*

**Questions???**  
**Contact Ellis Music Company**  
**1-802-234-6400**  
**www.ellismusic.com**